abstracta
Creating Soundscapes

Zen Pod Medium
Assembly instruction

abstracta
Creating Soundscapes

Set the floor module in balance.
Set screws are in the corners and in the middle (total 6 pce).
Please check if all the adjustable feets have support from the floor.

abstracta
Creating Soundscapes

A. 1 pce corner profile with hinges.
B. 3 pce corner profiles.
C. 1 pce middle profile with magnets for door. Front.
D. 1 pce middle profile. Rear.

abstracta
Creating Soundscapes

Corner profile (A) for left hung door.
Please note direction of the key hole!

abstracta
Creating Soundscapes

Press the corner profile inwards and check that the sealings are in correct position before tightening the nuts (2pce).

abstracta
Creating Soundscapes

Remove top plates from the roof module.

abstracta
Creating Soundscapes

Lifting the roof module in place.

Please note the position of the cables from the roof in combination with the left hung door.

abstracta
Creating Soundscapes

Nuts (2 pce) as fixation of the roof module to the corner profile.

abstracta
Creating Soundscapes

Middle profile (C) next to the door.
Please note the direction of the key hole.
Please note the magnets on this profile.

abstracta
Creating Soundscapes

Middle profiles (C & D). Screws for fixation to floor module and roof module.

abstracta
Creating Soundscapes

Top plates (2 pce) on the roof module.

abstracta
Creating Soundscapes

Floor carpet in position.
The carpet attached with self-adhesive tape.

* Please note!
Tight edge between carpet
and floor module door/glass.

abstracta
Creating Soundscapes

Lift the wall-panel in position.

abstracta
Creating Soundscapes

Attach wall panels with screw sleeve.

abstracta
Creating Soundscapes

Rear wall panels.

Narrow edge towards center profile.

Wide edge towards corner profile.

abstracta
Creating Soundscapes

Rear wall panels. Mounting to middle profile.

abstracta
Creating Soundscapes

Power cable from below.

Power cable from above.

abstracta
Creating Soundscapes

Power cable from below.

abstracta
Creating Soundscapes

Lift of glass panel in position. Use a pair of glass lifters.

abstracta
Creating Soundscapes

Cable connection. Rear middle profile.

abstracta
Creating Soundscapes

Cable connection. Front middle profile.

abstracta
Creating Soundscapes

Mounting of the cover profiles. Corners.

abstracta
Creating Soundscapes

Mounting of the cover profile in the corner with the door hinges.
Use a pair of clamps and a rubber club. Work from bottom to top.

abstracta
Creating Soundscapes

Mounting of the cover profiles. Middle.

abstracta
Creating Soundscapes

Lift the glass door in position. Use a pair of glass lifters.
Please note the door shall not be fully opened when lifted in position.

abstracta
Creating Soundscapes

Mounting of wooden handle on the glass door.
Please note that the screws on the sleeve shall be mounted downwards.
Allen key 3mm.